

Extraction from Mixing stations and dissolving vessel



Case Study

Project Location

United Kingdom

Sector

Pharmaceutical

Equipment Description

RotoClone N Size 6 Arrangement D

Our clients goal was to provide a local exhaust ventilation system for several mixing and weighing work stations, as well as extraction from a dissolving vessel. The client wanted the reliability of a wet scrubber and to avoid the requirement of handling the collected dust.

AAF supplied a RotoClone N which is perfectly suited to this wet and dry environment complete with exhaust fan, accoustics and electrical controls

Outcome: The system successfully provided the necessary local exhaust ventilation. By utilising a motorised drain valve to discharge small amounts of effluent under a timer control, together with electronic make up water control, AAF was also able to minimise the clients water usage.



For more information contact our sales team: +44 (0) 1670 713 477

www.aafintl.com



EMS 548984



FM 01873-ISO 9001

Better Air is Our Business®

AAF
POWER & INDUSTRIAL